

Torna a:
[Tecnica.htm](#)

Table with columns: Mast maker, owner, code, Bb, Sb, P0, P1, P2, P3, P4, P5, P6, P7, P8, P9, kg, 4570, 4000, 3500, 3000, 2500, 2000, 1500, 1000, 500, 0, ascisse della corda (X0-X8), ascisse dell'albero (x1-x9). Rows list various mast makers and their specifications.